







Montageanleitung
Hochschrankauszug "Dispensa Swing-x"

Assembly Instruction
Larder pull-out "Dispensa Swing-x"




Eigengewicht + Beladung
Empty weight + Load




1



2




A





B




C




3




5




A




Top



B



6




Justieranleitung

Hochschrankauszug "Dispensa Swing-x"



Adjusting Instruction


Larder pull-out "Dispensa Swing-x"



+







= max.
100 kg









Eigengewicht + Beladung
Empty weight + Load

1




1a








2

3



4





5





6





1 Demontage der Front
Disassembling front





2 Montage der Front
Assembling front



3 Demontage der Schiene
Disassembling runner



4 Montage der Schiene
Assembling runner



Die technischen Darstellungen und Maßangaben -auch bei Abbildungen und Zeichnungen- sind unverbindlich. Konstruktionsverbesserungen sind vorbehalten